

ExP2 Fintek Series

mPCIe/M.2 to Serial COM

User Manual

Rev 1.2

Copyright Information
2005-2023 ©Innodisk Corporation. All Rights Reserved
Innodisk™ is trademark or registered trademark of Innodisk Corporation.
This document is subject to change and revision without notice. No part of this document may be reproduced in any form by any photographic, electronic, mechanical or other means, or used in any information storage and retrieval system, without prior written permission from Innodisk Corporation.
All other product and brand names in this document are trademarks or registered trademarks of their respective owners.

版權說明

2005-2023 ©宜鼎國際股份有限公司

Innodisk™ 是宜鼎國際股份有限公司之註冊商標。

本文件得不經通知即更改或修訂。本文件中出現任何文字敘述、文件格式、圖形、照片、方法及過程等內容，除另特別註明，版權均屬宜鼎國際股份有限公司所有，受到相關之智慧財產權保護法之保障。任何個人、法人或機構未經宜鼎國際股份有限公司的書面 (包括電子文件) 授權，不得以任何形式複製或引用本文件之全部或片段。

其他出現在本文件的品牌或產品乃歸屬原公司所有之商標或註冊。

2005-2023 © Innodisk Corporation. All Rights Reserved

Revision History

Revision	Date	Description
1.0	2023/03/28	Initial Release
1.1	2023/09/12	Add boot config and boot up script
1.2	2024/04/15	Add 2.10 FAQ and 2.10.1 workaround document for RHEL kernel 5.14 API type not compatible with mainstream kernel.

2005-2023 © Innodisk Corporation. All Rights Reserved

Table of Contents

Revision History ..... **ii**
Table of Contents ..... **iii**
Overview **1**
1. Windows **2**
1.1. Install Driver 2
1.2. Fix mode module 4
1.3. Switch Mode Module by Software 4
2. Linux **7**
2.1. lspci 7
2.2. dmesg |grep tty 7
2.3. Boot Config 8
2.4. Install Driver 9
2.5. Install Mode-Control Tool “serial_f81504_tool” 10
2.6. serial_f81504_tool README 11
2.7. Fix mode module 11
2.8. Switch Mode by Software 12
2.9. Boot Up Script 14
2.10. FAQ 14
2.10.1. For RHEL kernel 5.14 14

2005-2023 © Innodisk Corporation. All Rights Reserved

Overview

This manual describes how to implement ExP2 Fintek series mPCIe/M.2 to Serial COM cards of the following products.


Product No.	RS232	RS485	RS422	Switch Method
EMP2-X206	O	O	O	Software
EMP2-X406	O	O	O	Software
EMP2-X207	O	X	X	Fixed Mode
EMP2-X407	O	X	X	Fixed Mode
EGP2-X203	O	X	X	Fixed Mode
EGP2-X403	O	X	X	Fixed Mode
EGP2-X204	O	O	O	Software
EGP2-X404	O	O	O	Software


2005-2023 © Innodisk Corporation. All Rights Reserved

1. Windows


1.1. Install Driver


This section is applicable to ALL products. Double click the driver package to start. Need reboot after installing the driver.






2005-2023 © Innodisk Corporation. All Rights Reserved







2005-2023 © Innodisk Corporation. All Rights Reserved

1.2. Fix mode module

Can use directly after installing driver.


Product No.	RS232	RS485	RS422	Switch Method
EMP2-X207	O	X	X	Fixed Mode
EMP2-X407	O	X	X	Fixed Mode
EGP2-X203	O	X	X	Fixed Mode
EGP2-X403	O	X	X	Fixed Mode

1.3. Switch Mode Module by Software


This section is applicable to following products.


Product No.	RS232	RS485	RS422	Switch Method
EMP2-X206	O	O	O	Software
EMP2-X406	O	O	O	Software
EGP2-X204	O	O	O	Software
EGP2-X404	O	O	O	Software

In Device Manager, right click the mouse to enter “properties” in ***“Communications ports”***.




2005-2023 © Innodisk Corporation. All Rights Reserved





2005-2023 © Innodisk Corporation. All Rights Reserved




2005-2023 © Innodisk Corporation. All Rights Reserved

2. Linux

Here we use Ubuntu 22.04 for example.

2.1. lspci

Check if the device exists in the system.



2.2. dmesg |grep tty

Shows how many Fintek serial ports are in the system, in this case ttyS4 to ttyS7.




2005-2023 © Innodisk Corporation. All Rights Reserved

2.3. Boot Config

1. Prepare tools:
   - Ubuntu
     $ sudo apt-get update
     $ sudo apt-get dist-upgrade
     $ sudo reboot
     $ sudo apt-get install gcc make kernel-package

2. Boot Configuration:
   - Ubuntu
     $ sudo nano /etc/default/grub
     add "8250.nr_uarts=32 initcall_blacklist=serial_pci_driver_init" to "GRUB_CMDLINE_LINUX_DEFAULT"
     $ sudo update-grub
     $ sudo reboot




2005-2023 © Innodisk Corporation. All Rights Reserved

2.4. Install Driver

This section is applicable to ALL products.

Step1. Go to driver folder.
Step2. Type command “#make”.
Step3. Type command “#make install”
Step4. Type command “#reboot”




2005-2023 © Innodisk Corporation. All Rights Reserved

2.5. Install Mode-Control Tool “serial_f81504_tool”

This section is applicable to following products.


Product No.	RS232	RS485	RS422	Switch Method
EMP2-X206	O	O	O	Software
EMP2-X406	O	O	O	Software
EGP2-X204	O	O	O	Software
EGP2-X404	O	O	O	Software

Step1. Go to tools folder.
Step2. Type command “#make”.
Step3. Type command “#make install”
Step4. Type command “#reboot”



2005-2023 © Innodisk Corporation. All Rights Reserved

2.6. serial_f81504_tool README



2.7. Fix mode module

Can use directly after installing driver.

Product No.	RS232	RS485	RS422	Switch Method
EMP2-X207	O	X	X	Fixed Mode
EMP2-X407	O	X	X	Fixed Mode
EGP2-X203	O	X	X	Fixed Mode
EGP2-X403	O	X	X	Fixed Mode

2005-2023 © Innodisk Corporation. All Rights Reserved

2.8. Switch Mode by Software

This section is applicable to following products.

Product No.	RS232	RS485	RS422	Switch Method
EMP2-X206	O	O	O	Software
EMP2-X406	O	O	O	Software
EGP2-X204	O	O	O	Software
EGP2-X404	O	O	O	Software

After installing driver and control tools, you can simply execute below command to initial the COM ports.


Notice, all serial_f81504_tool control tools need to be executed as root.

- COMMAND: serial_f81504_tool -i
  The serial_f81504_tool -i will help you check if the driver has been loaded on the system and setup all ports following the configuration file (/etc/serial_f81504.cfg). If the configuration file did not exist, it will create a default one for you, all ports will be configured as RS232 mode by default.


  Notice that, the serial_f81504_tool -i must be executed after system boot up every time to make sure the driver loaded well and all ports be configured as you want.

- COMMAND: serial_f81504_tool -t <port> -m <mode>
  The <port> specify which port you want to configure, And the <mode> specify the target mode, Mode table (M0/M1/M2):
  0: 000 - **RS422**
  1: 001 - **RS232**
  2: 010 - **RS485**
  4: 100 - **RS422R** (with termination)
  6: 110 - **RS485R** (with termination)

2005-2023 © Innodisk Corporation. All Rights Reserved



- COMMAND: serial_f81504_tool –l
  You can check currently setting



- COMMAND: serial_f81504_tool –r (need reboot system after setting)
  Reset all port to default mode RS232.

2005-2023 © Innodisk Corporation. All Rights Reserved

2.9. Boot Up Script

We provide Linux boot up script to initial serial interface automatically after system boot up.

Run the following command in the “release” folder to add boot up script.

- $ chmod +x add_2_boot.sh
- $ ./add_2_boot.sh


Run the following command in the “release” folder to remove boot up script.

- $ chmod +x remove_boot.sh
- $ ./ remove_boot.sh

2.10. FAQ

2.10.1. For RHEL kernel 5.14

F81504 will build failed on RHEL kernel 5.14.



It’s due to the RHEL kernel API not the same with mainstream’s. Customer must modify f81504_serial.c near line 290, change the #if 1 to #if 0 and re-build driver.

```
284:#if LINUX_VERSION_CODE >= KERNEL_VERSION(2, 6, 36)
285:#if LINUX_VERSION_CODE >= KERNEL_VERSION(6, 1, 0)
286: void f81504_set_termios(struct uart_port *port, struct ktermios *termios,
287:                         const struct ktermios *old)
288:#else
289:#if 1
290: void f81504_set_termios(struct uart_port *port, struct ktermios *termios,
291:                         struct ktermios *old)
292:#else
293: // for centos stream kernel 5.14.0-390-el9
294: void f81504_set_termios(struct uart_port *port, struct ktermios *termios,
295:                         const struct ktermios *old)
296: #endif
297: #endif
298: {
299:         struct pci_dev *dev = container_of(port->dev, struct pci_dev, dev);
300:         struct f81504_priv *priv = pci_get_drvdata(dev);
301:         unsigned int baud = tty_termios_baud_rate(termios);
```

2005-2023 © Innodisk Corporation. All Rights Reserved